

Altair MotionView 2019 Tutorials

MV-1032: Model Building and Simulation using Wizards

altairhyperworks.com

### MV-1032: Model Building and Simulation using Wizards

In this tutorial, you will learn:

- About the Assembly and Task Wizards in MotionView
- How to build a model using the Assembly and Task Wizards
- How to view a standard report
- How to modify a model and compare results using the Report Template

Model Wizards are powerful tools in MotionView that can be used to quickly build models with standard topology that is used repeatedly. There are two standard wizards available: the **Assembly Wizard** and the **Task Wizard** (which work in conjunction with one another). Both of these wizards rely on a library of pre-saved system, analysis, and report definition files to automate the processes of building models, analyzing them, and post-processing the results. The wizard mechanics are shown in the flowchart below:



- A collection of systems and analyses are stored as a library.
- The **Assembly Wizard** presents the user with various options to select systems to instantiate (in the form of a series of panels).
- The systems selected by the user in the panels are instantiated using the system definitions contained in the MotionView client library, thereby assembling the model comprised of different systems. An **Attachment Wizard** follows, which is used to select possible attachment options for each system that is instantiated.
- On the model is built, the **Task Wizard** is invoked in order to attach applicable events to the model. The selected analysis is instantiated using the analysis definition stored in the library.



# Exercise: Automated Modeling and Analysis Using Wizards

In this exercise, we will build a suspension model of a vehicle using the standard wizard library available in MotionView. A static ride event will be attached to this model using the **Task Wizard**. The model will then be solved in MotionSolve and an automated report will be generated.

## Step 1: Building a front suspension model using the Assembly Wizard.

- 1. Start a new session in MotionView.
- 2. On the **Model** menu, click **Assembly Wizard**.

The Assembly Wizard dialog is displayed.

📣 Assembly Wizard - Model Type			<b>—</b>
			Page 1 of 7
Select the model type			
<ul> <li>Front end of vehicle</li> </ul>			
<ul> <li>Rear end of vehicle</li> </ul>			
○ Full vehicle			
C Full vehicle with advanced driver			
C Powertrain model			
Reset Selection Message Log	< Back	Next >	Cancel

- 3. For Model type, select *Front end of vehicle*.
- 4. Click **Next**.
- 5. For **Drive type**, select *Front Wheel Drive*.
- 6. Click **Next**.
- 7. From the **Primary Systems for Front end of vehicle** dialog, specify the following:
  - Vehicle body = Body fixed to ground
  - Front subframe = None
  - Front suspension = Front SLA susp (1 pc. LCA)
  - Steering linkage = Rackpin steering
  - Powertrain = None
- 8. Click **Next**.



- 9. From the **Select steering subsystems** dialog, specify the following:
  - Steering Column = Steering column 1 (not for abaqus)
  - Steering Boost = None
- 10. Click *Next*.
- 11. From the **Select springs, dampers and stabilizer bars** dialog, select the following:
  - Front shocks = Frnt shock absorber (with inline jts)
  - Front stabilizer bars = None
- 12. Click Next.
- 13. From the **Select jounce and rebound bumpers** dialog, set the options to **None**, and click **Next**.
- 14. From the **Select Driveline Systems** dialog, set the **Front Driveline** to *Independent Forward*, and click *Next*.

All of the required systems that are necessary to build a front suspension model have now been selected.

15. Click *Next* to load the assembled model and bring up the **Attachment Wizard**.

The **Attachment Wizard** shows the attachment choices which are available for each sub-system. In this exercise, we will simply review the options in each sub-system and accept the default selections.

- 16. From the **Attachment Wizard**, review the choices for each sub-system and click *Next* until the last page of the dialog is reached.
- 17. Click *Finish*.

Your model should look as follows:





#### A brief description of the model:

This model represents a front end suspension of a vehicle with a Short Long Arm type (also known as Wishbone) of suspension and a steering system. The vehicle body is fixed to ground. The upper and lower control arms of the suspension are attached to the vehicle body at one end through bushings, while they are connected to a knuckle on the other end through ball joints. A wheel hub (no graphics for this body are in the model) is mounted on the knuckle through a revolute joint. The wheel is fixed to the wheel hub.

The steering system consists of a rack with a translation joint with a rack housing (through a dummy body). The ends of the rack are connected to a tie rod at each end through ball joints and the other end of the tie rod is connected to the steer arm of the knuckle through ball joints. The rack gets its movement from the steering column through a coupler constraint between the rack and the pinion.

#### Step 2: Adding a static ride analysis task using the Task Wizard.

The **Analysis Task Wizard** allows you to assign an event analysis to the model using a wizard. This default suspension wizard is configured such that the available analyses choices are dependent on the system selections made in the **Assembly Wizard**. Since this is a half-vehicle model, only events that are applicable for a half-vehicle model are available. A full vehicle model would contain a different set of analysis events.

In this step, we will add a static ride analysis for the suspension assembly. Through this analysis, the kinematic characteristic of the suspension can be studied for varying vertical positions of the wheels. Both wheels are exercised such that they move vertically along the same direction.

- 1. On the Analysis menu, click Task Wizard.
- 2. In the **Task Wizards Front end tasks** dialog select the *Front end task* as *Static Ride Analysis* from the pull down menu.
- 3. Click Next.
- 4. Read the information in the dialog box.
- 5. Click *Finish*.

The **Vehicle parameters** dialog is displayed. Vehicle parameters such as wheelbase, jounce, and rebound distances can be changed in this dialog.



6. Retain the current parameters and click *Finish*.Your model should look as follows:



The static ride analysis event consists of a pair of jacks that are attached to the wheels at the tire contact patch location. The jacks are actuated through Actuator Forces that exercises them in the vertical direction in a sinusoidal fashion.

The model tree in the **Project Browser** now includes an analysis called **Static ride analysis**. It is possible to add many different analysis tasks to the same model, however only one analysis task may be active at one time.

- 7. Go to the **Project Browser**, right-click on **Model** and select **Rename** (or left click on **Model** and press **F2** on the keyboard).
- 8. Rename the Model label to My Front SLA Suspension.
- 9. Expand the *Static ride analysis* folder and also the *Forms* folder (located underneath) by clicking the + sign next to each folder in the **Project Browser**.
- 10. Select the *Static Ride Parameters* Form.

The **Forms** panel is displayed.

- 11. Change the values for Jounce travel (mm) and Rebound travel (mm) to 50.0.
- 12. Click kand save the model as sla\_ride.mdl in your <working directory>.



#### Step 3: Running the simulation and viewing a report.

The static ride simulation is a 10 second quasi-static run. Within the 10 seconds the jack moves in jounce (vertically upwards), then moves down until the rebound position is reached (distance from the initial position downwards), and then back to its initial position. The amount of travel is as per the distance specified in the Static Ride parameters form.

- 1. Click the *Run* icon, 🕗, on the **General Actions** toolbar.
- 2. Save your model as sla\_rigid.xml in your <working directory>.
- 3. Click on the *Run* button to submit the simulation job to MotionSolve.
- 4. After the job is completed, close the **Run** window and the **Message Log**.
- 5. From the **Analysis** menu, click *View Reports*.

The **View Reports** dialog is displayed.

6. Select *Front Ride-MSolve SDF based Report My Front SLA Supsension* and click *OK*.

This analysis comes with a Standard Report Template that plots the results and loads the animation in subsequent pages.

7. Once the process of adding the pages is complete, use the **Previous Page/Next** 

**Page** buttons (located at the upper right corner of the window, below the menu bar area and above the graphics area) to navigate and review the plots and animation pages.

8. The last page is the TextView client with an open Suspension Design Factors (SDF) report. This report lists the suspension factors at each time interval of the simulation.

#### How does viewing pre-specified results work?

A report that refers to a report template file (a template that contains plot and animation definitions) can be defined in the MotionView model using the \*Report() MDL statement. Whenever a model containing such a report definition is submitted to a solver, MotionView writes a record of the report into a log file named *.reports*. You can specify the location of this file with the preference file statement

\*RegisterReportsLog(path). The default location of the .reports file is:

UNIX - <user home>

PC - C:\Documents and Settings\<user>

The path to the .reports file can also be set by selecting the **Set Wizard path** option under the **Model** menu.

When **View Reports** from the **Analysis** menu is selected, MotionView displays the contents of the .reports file in the **Reports** dialog. When you select a report from the dialog, MotionView loads the requested report definition file into your session.



Below is a sample entry from the .reports log file:

```
Front Ride - MSolve Report Front Static Ride
02/10/XX 06:07:58
E:/Altair/hw/mdl/mdllib/Libs/Tasks/adams/Front/Ride/ms_rep_kc_front.tpl
*Report(rep_kc_frnt_mc, Front Ride - MSolve Report, repdef_kc_frnt,
"E:/Temp/sla_rigid.h3d", "E:/Temp/sla_rigid.h3d", "E:/Temp/sla_rigid.plt")
```

The first line contains the report label, model label, and the date and time when the solver input files were saved. This information is contained in the **Reports** dialog. It is recommended that you give your models specific names, otherwise they will be labeled **Model**.

Line 2 contains the name of the report definition file that the report is to be derived from.

Line 3 contains an MDL statement called \*Report(). This statement specifies the report definition variable name along with the required parameters. Refer to the *MDL* online help for more information.

#### Step 4: Modifying model parameters and comparing the results.

Next, we will modify the suspension parameters. After the simulation is run again, the results can then be compared.

- 1. Return to the **MotionView** 🗲 client page.
- 2. Right-click on *Frnt SLA susp (1 pc. LCA)* in the **Project Browser** and select *Data Summary*.

The Data Summary dialog is displayed.

Points Vectors Curves Bodies	ADV Joints	Couplers	Bushings   Fields	Spring	Dampers   I	Beams	Poly Beams	Forces	Motions	Contects	Sensors	<u>•</u> )
	×	Y	. z	Sym	×		Y	2				-
nt SLA susp (1 pc. LCA)	10	N 95			1 0000							
Wheel CG	1000.000	-758.000	1000.000	P	Symmetric	Sv	mmetric	Symmetric				
Mheel center	1000.000	-750.000	1000.000	P	Symmetric	SV	mmetric	Symmetric				
Spindle align	1000.000	-650.000	1000.000	P	Symmetric	SV	mmetric	Symmetric				
Inuckle CG	1000.000	-650.000	1000.000	P	Symmetric	Sy	mmetric	Symmetric				
Lwr ball #	984,890	-675.590	904.520	P	Symmetric	SV	mmetric	Symmetric				
Upr ball #	1026.450	-605.230	1167.100	P	Symmetric	Sy	mmetric	Symmetric				
Ot terod ball it	1120.000	-675.000	1000.000	F	Symmetric	Sv	mmetric	Symmetric				
LCA CG	1043 040	-458 530	895,890	P	Symmetric	SV	mmetric	Symmetric				
LCA fint bush	932,150	-196.300	929.640	P	Symmetric	Sv	mmetric	Symmetric				
LCA rear bush	1270.250	-286.640	924,900	P	Symmetric	SV	mmetric	Symmetric				
UCACG	1026.450	-605.230	1167.100	P	Symmetric	Sy	mmetric	Symmetric				
UCA fmt bush	877.020	-405.230	1180.170	P	Symmetric	Sy	mmetric	Symmetric				
UCA rear bush	1175.880	-405.230	1154.020	P	Symmetric	Sy	mmetric	Symmetric				
Spring upr	1043 040	-458 530	1065.890	P	Symmetric	SV	mmetric	Symmetric				
Spring lwr	1043.040	-458.530	915.890	P	Symmetric	Sy	mmetric	Symmetric				
Shock upr bush	1043.040	-458.530	1195.890	9	Symmetric	Sy	mmetric	Symmetric				
Shock lwr bush	1043.040	-458.530	915.890	F	Symmetric	Sy	mmetric	Symmetric				
Fint shock absorber ( with inline its )					des Romana and			te de menere				
Shock rod CG	1043.040	-458.530	1120.890	F	Symmetric	Sy	mmetric	Symmetric				
Shk rod lwr	1043.040	-458.530	1045.890	9	Symmetric	Sy	mmetric	Symmetric				
Shk upr bush ex	1143.040	-458.530	1195.890	P	Symmetric	Sy	mmetric	Symmetric				
Shock tube CG	1043.040	-458.530	992 390	P	Symmetric	Sy	mmetric	Symmetric				
Shk tube upr	1043.040	-458.530	1068.890	9	Symmetric	Sy	mmetric	Symmetric				
Shk lwr bush ax	1143.840	-458.530	915.890	P	Symmetric	Sy	mmetric	Symmetric				
Fmt coil spring	Accession .		10000000	almebra.	2010-000	: 308		0000-000				

- Change the X and Y coordinates of LCA frnt bush by -5 and +5 respectively (for example, if the existing value of X is 932.15, append -5 to it so that the expression is 932.15-5).
- 4. Similarly, change the X and Y coordinates of UCA rear bush by +3 and -5 respectively. In addition, change the Z coordinate of Lwr ball jt by +10.
- 5. Click on the *Bushings* tab and change the KZ values of LCA frnt bush and UCA frnt bush by -200 and +200 respectively.
- 6. Click the *Close* button to close the **Data Summary** dialog.
- 7. Go to the **Run** panel <sup>(1)</sup>, and specify sla\_ride\_change.xml as the new file name for the xml file.
- 8. Click the *Run* button.
- 9. After the job is completed, close the **Run** window and the **Message Log**.
- 10. From the Analysis menu, click View Reports.
- 11. Select the latest report (the report located at the top of the list) and click **OK**.

The results from the latest run will be overlayed in the plot and animation windows. Compare the plots.

12. In the **Hyperview** is client (page 17 of the session), use the **Change Model** dropdown menu (located in the **Results Browser**) to change the active result to sla ride baseline.h3d as shown below:

Session	Results						
7	S 🖬 🕯			$\searrow$			
C:\Altair\ti	utorials\working	directory\sla	_ride_ba	seline.h3d	▲ _		
C:\Altair\tutorials\working directory\sla_ride_baseline.h3d C:\Altair\tutorials\working directory\sla_ride_change.h3d							
▲ Time =	0.000000				•		
		<b></b>	• 🗟	📄 🥮	1		

- 13. Click the **Entity Attributes** panel button **Visualization** toolbar to enter the **Entity Attributes** panel.
- 14. Activate the **Auto apply mode** check box (located in the middle portion of the panel).
- 15. Select a color from the color palette and click the **All** button.

All graphics belonging to the active result will change to the selected color.

16. Repeat steps 12 to 14 for sla\_ride\_change.h3d, however be sure to select a different color from the color palette.



17. From the **Animation** toolbar, click the **Start/Pause Animation** button **b** to animate the results.

View the animation and observe the differences between the two overlayed models.

- 18. Navigate back to the **MotionView**  $\clubsuit$  page and save the model  $\overline{k}$ .
- 19. Click the **Save Session** icon and an the **Standard** toolbar and save your session as my\_susp\_analysis.mvw in your working directory.

The model, plot, and animation information is saved in the session file.